




GUITAR SUITCASE AMPLIFIER (AG-5) OPERATION MANUAL



AG-5 CONTROLS

- INPUT**..... 1/4" jack for instrument input
VOLUME..... Adjusts the volume of the instrument
TONE Controls frequency output, from darker to brighter
- PHONES** For headphone monitoring; deactivates AG-5 speaker when used
AUX IN..... 1/8" connector for incoming external stereo signal
- DC JACK**..... connector for included 9V DC adapter (saves 9V battery when in use)
POWER..... Turns AG-5 on or off

AG-5 SPECIFICATIONS

- OUTPUT POWER**5 watts RMS
SPEAKER5" 8-Ohm driver
DIMENSIONS350mm W, 210mm H, 125mm D
WEIGHT3 Kg
BATTERY9-volt (6F22 type)

WARNING: If your AG-5 fails to function, please contact your dealer or distributor. **Do not remove the back panel of the amplifier, while it is connected to a wall socket, under any circumstances.**